



FLASH

Moving Head LED 15W

User Manual



Maintenance

1. Please keep the light in dryness and avoid using it in wet places.
2. Using it intermittently can extend its life.
3. Attention to clean the fan and lens usually in order to get the ventilating effects and lighting effects better.
4. Please do not wipe the dust using organic solvents to avoid damaging the product.

Statement

The product has good capability and intact packing when it leaves the factory. All of the user should comply with the above warning items and manual, any misuse or cause of the damages are not included in our guarantee, and also can't be responsible for any malfunction & problem owing to ignoring the manual.

Please forgive that we will not be notified for technical changes.

Attention Item

1. For guaranteeing the life of the product, please don't put it on a wet place and also not use it in a place over 40 degrees.
2. Please don't lay the product on an unfixable or shakable place.
3. Ask for a professional to maintain the product in order to avoid the danger of getting an electric shock.
4. Power supply should not be changed over +/- 10% while the light is using, it will decrease the life of the lamp if the power is too high, but it will be influenced by the luminosity if the power is too low.
5. After power off, if it is needed again, please cool down for over 20 minutes.
6. Please look through the manual to ensure the product can be used normally.

Product introduction

- Power supply: AC230V, 50Hz
- Power consumption: 50W
- Fitting lamp: LED 15W RGB
- DMX-control-channels: 5 or 13, select from control board











- Color: RGB color-mixture
- Gobo-wheel: 9 gobo + open + rainbow
- Shuttle: Flash rate: 0-10Hz
- Dimmer: 0-100% mechanic dimmer
- Maximum PAN-movement: 540
- Maximum TILT-movement: 270
- Master/ Slave activated by sound at pre-programmed function.

13 Control Channel

Accept DMX512 control channel, detail as follow:

Channel	DMX-value	Feature
1 - PAN	0~255	540°
2 - PAN 16 bitów	0~255	16 bit PAN
3 - TILT	0~255	270°
4 - TILT 16 bitowy	0~255	16 bit TILT
5 - speed	0~255	PAN/ TILT controllable speed with decreasing
6 - shutter	0~7	Close
	8~134	100%-0% electrical dimmer
	135~239	STROBE effect with increasing speed
	240~255	Open
7 – LED_RED	0~255	Dimmer for RED 0~100%
8 – LED_GREEN	0~255	Dimmer for GREEN 0~100%
9 – LED_BLUE	0~255	Dimmer for BLUE 0~100%
10 - LED macro	0~7	No function
	8~21	White
	22~35	Red
	36~49	Green
	50~63	Blue











	64~77	Cyan
	78~91	Magenta
	92~105	Yellow
	106~119	Purple
	120~133	Orange
	134~147	Chartreuse
	148~161	Pink
	162~175	Brown
	176~189	Gold
	190~203	Crimson
	204~217	Violet
	218~231	Crape
	232~255	Movable macro
11 – LED speed	0~255	
12 – Auto Program	0~7	No function
	8~22	Auto program 1
	23~37	Auto program 2
	38~52	Auto program 3
	53~67	Auto program 4
	68~82	Auto program 5
	83~97	Auto program 6
	98~112	Auto program 7
	113~135	Auto program 8
	136~142	Sound control 1
	143~157	Sound control 2
	158~172	Sound control 3
	173~187	Sound control 4
	188~202	Sound control 5

	203~217	Sound control 6			
	218~232	Sound control 7			
	233~255	Sound control 8			
13 - Gobo					
	0~12	13~25	26~38	39~51	52~64
					
	65~77	78~90	91~103	104~116	117~127
	128~191	Positive rainbow effect with increasing speed			
192~255	Negative rainbow effect with increasing speed				

5 Control Channel

Accept DMX512 control channel, detail as follow:

Channel	DMX-value	Feature
1 PAN	0~255	540°
2 TILT	0~255	270°
3 Shutter	0~7	Close
4 LED makro	8~134	100%-0% mechanic dimmer
	135~239	Strobe effect with electric al speed
	240~255	Open
	0~7	No function
	8~21	White
	22~35	Red
	36~49	Green
	50~63	Blue
	64~77	Cyan
	78~91	Magenta

	92~105	Yellow			
	106~119	Purple			
	120~133	Orange			
	134~147	Chartreuse			
	148~161	Pink			
	162~175	Brown			
	176~189	Gold			
	190~203	Crimson			
	204~217	Violet			
	218~231	Crape			
	232~255	Movable macro			
5 Gobo	 0~12	 13~25	 26~38	 39~51	 52~64
	 65~77	 78~90	 91~103	 104~116	 117~127
5 Gobo	128~191	Positive rainbow effect with increasing speed			
	192~255	Negative rainbow effect with increasing speed			

Control Board


When navigating the menu:

Use the <UP> button to move up.

Use the <DOWN> button to move down.

Use the <ENTER> button to move right.

Use the <MODE> button to move left, Or to scroll through the left-most items In the menu map.



13CH → **13CH** Channel mode: 13 channels
 → **5CH** Channel mode: 5 channels

PAS4 → **PAS4** PAN 540°
 → **PA36** PAN 360°
 → **PA18** PAN 180°


t.27 → **t.27** TILT 270°
 → **t.18** TILT 180°
 → **t.9** TILT 90°

LAn → **LAn** Lamp on
 → **LAr** Lamp off

rESt System reset

LoAd Lode default

Controller connection diagram



XLR-connection

