



CSP039

CSP039 MXR[®] Duke of Tone[™] Overdrive

Designed in conjunction with indie pedal builder Analog Man, the MXR Duke of Tone Overdrive is for players who want to add a touch of warmth and grit to their rig while allowing the natural tone and feel of their high-end gear to shine.

jimdunlop.com/csp039

External Controls



- 1 Footswitch toggles effect on/off (white LED indicates on)
- 2 OD/BOOST/DIST switch sets clipping mode
- 3 VOLUME knob adjusts overall output level
- 4 DRIVE knob adjusts overdrive intensity
- 5 TONE knob adjusts overall EQ

Basic Operation

Power

The MXR® Duke of Tone™ Overdrive is powered by the Dunlop ECB003 9-volt adapter or an MXR® Brick™ Series power supply. This pedal cannot be powered by a battery.

Directions

1. Run an instrument cable from your instrument to the CSP039's INSTRUMENT jack and another instrument cable from the CSP039's AMPLIFIER jack into your amplifier's input.

2. Start with knobs set to 12 o'clock.

3. Turn effect on by depressing the footswitch.

4. Use OD/BOOST/DIST switch to select your preferred clipping style:

OD mode engages soft clipping for a touch of grit and compression. Boost mode bumps up your signal loudly and clearly with no clipping. Distortion mode engages hard clipping for a grittier, more compressed sound and a bump in output level.

5. Rotate VOLUME knob clockwise to increase overall volume or counterclockwise to decrease it.

6. Rotate DRIVE knob clockwise to increase overdrive intensity or counterclockwise to decrease it.

7. Rotate TONE knob clockwise for a brighter sound or counterclockwise for a warmer sound.

Specifications

Input Impedance	> 450 k Ω
Output Impedance	< 10 k Ω
Bypass	True Bypass
Current Draw	6 mA
Power Supply	9 volts DC